



Supplied hardware for KX65

Use the supplied hardware in place of the factory hardware when mounting your FMF silencer. The shorter bolt is used for the front mount and the longer for the rear. Use a supplied spacer with each bolt and place between the silencer and the subframe.

(101507, 000782)



Supplied hardware for KX65

Use the supplied hardware in place of the factory hardware when mounting your FMF silencer. The shorter bolt is used for the front mount and the longer for the rear. Use a supplied spacer with each bolt and place between the silencer and the subframe.

(101507, 000782)



Supplied hardware for KX65

Use the supplied hardware in place of the factory hardware when mounting your FMF silencer. The shorter bolt is used for the front mount and the longer for the rear. Use a supplied spacer with each bolt and place between the silencer and the subframe.

(101507, 000782)



Supplied hardware for KX65

Use the supplied hardware in place of the factory hardware when mounting your FMF silencer. The shorter bolt is used for the front mount and the longer for the rear. Use a supplied spacer with each bolt and place between the silencer and the subframe.

(101507, 000782)



Supplied hardware for KX65

Use the supplied hardware in place of the factory hardware when mounting your FMF silencer. The shorter bolt is used for the front mount and the longer for the rear. Use a supplied spacer with each bolt and place between the silencer and the subframe.

(101507, 000782)



Supplied hardware for KX65

Use the supplied hardware in place of the factory hardware when mounting your FMF silencer. The shorter bolt is used for the front mount and the longer for the rear. Use a supplied spacer with each bolt and place between the silencer and the subframe.

(101507, 000782)



Supplied hardware for KX65

Use the supplied hardware in place of the factory hardware when mounting your FMF silencer. The shorter bolt is used for the front mount and the longer for the rear. Use a supplied spacer with each bolt and place between the silencer and the subframe.

(101507, 000782)



Supplied hardware for KX65

Use the supplied hardware in place of the factory hardware when mounting your FMF silencer. The shorter bolt is used for the front mount and the longer for the rear. Use a supplied spacer with each bolt and place between the silencer and the subframe.

(101507, 000782)